



light only mini

installation instruction




Step 1




constant current (mA)	typical forward voltage (V)	typical power (W)
350	16,9	5,9
500	17,4	8,7
700	18,2	12,7
850	18,5	15,7

Step 2



Connect the wires with the connectors for serial connection, respect polarity combine with a prado LED-driver.

Step 3



Twist the luminaire as desired.

			IP 44	CE			Replace glass lens when broken. Luminaire shall only be used together with glass lens.
--	--	--	-------	----	--	--	---